
```
In [1]:
         import pandas as pd
          import numpy as np
         import matplotlib.pyplot as plt
        # Load CSV data into a DataFrame
In [13]:
         data = pd.read_csv('sensor data.csv')
In [14]: # Display the first few rows of the DataFrame
         print("First few rows of the sensor data:")
         print(data.head())
         First few rows of the sensor data:
                   Timestamp Proximity
         0 09-05-2024 08:00
                                     10
         1 09-05-2024 08:01
                                     12
         2 09-05-2024 08:02
                                     15
         3 09-05-2024 08:03
                                     13
         4 09-05-2024 08:04
                                     11
In [27]: # Basic data statistics
         print("\nData statistics:")
         print(data.describe())
         Data statistics:
                Proximity
                   20.000
         count
         mean
                   12.900
                    3.959
         std
         min
                    6.000
                   10.000
         25%
         50%
                   12.500
         75%
                   16.000
         max
                   20.000
In [28]: # Data Cleaning: Remove rows with missing values
         data.dropna(inplace=True)
In [29]:
         # Data Cleaning: Remove outliers (assuming Proximity values above 30 are outliers)
         data = data[data['Proximity'] <= 30]</pre>
        # Check for missing values
In [30]:
         missing values = data.isnull().sum()
         print("\nMissing values:")
         print(missing_values)
         Missing values:
         Timestamp
         Proximity
                      0
         dtype: int64
In [31]: # Data analysis
         # Plotting the proximity sensor data over time
         plt.figure(figsize=(10, 6))
         plt.plot(data['Timestamp'], data['Proximity'], color='blue', marker='o', linestyle=
         plt.title('Proximity Sensor Data Over Time')
         plt.xlabel('Timestamp')
         plt.ylabel('Proximity')
         plt.xticks(rotation=45)
         plt.grid(True)
         plt.tight_layout()
         plt.show()
```



```
# Convert Timestamp column to datetime format
In [32]:
          data['Timestamp'] = pd.to_datetime(data['Timestamp'])
         # Sort data by Timestamp
In [33]:
         data.sort_values(by='Timestamp', inplace=True)
In [34]:
         # Calculate dwell time (time difference between consecutive sensor readings)
          data['Dwell_Time'] = data['Timestamp'].diff().dt.total_seconds()
         # Remove rows with negative or NaN dwell time (due to first readings or missing dat
In [35]:
          data = data[data['Dwell_Time'].notnull() & (data['Dwell_Time'] >= 0)]
        # Plot dwell time distribution
In [36]:
         plt.figure(figsize=(10, 6))
         plt.hist(data['Dwell_Time'], bins=20, color='skyblue', edgecolor='black')
         plt.title('Dwell Time Distribution')
         plt.xlabel('Dwell Time (seconds)')
          plt.ylabel('Frequency')
         plt.grid(True)
          plt.tight layout()
          plt.show()
```

Dwell Time Distribution

17.5

15.0

12.5

7.5

5.0

2.5

Dwell Time (seconds)


```
# Calculate average dwell time
In [37]:
         avg_dwell_time = data['Dwell_Time'].mean()
         print("Average Dwell Time:", avg_dwell_time, "seconds")
         Average Dwell Time: 60.00000000000014 seconds
         # Load CSV data into a DataFrame
In [69]:
         data = pd.read_csv('Flowrate_sensordata.csv')
In [70]:
         # Display the first few rows of the DataFrame
         print("First few rows of the flow rate data:")
         print(data.head())
         First few rows of the flow rate data:
           Timestamp Flowrate
         0 08:00:00
                          10.5
         1 08:01:00
                          11.2
         2 08:02:00
                          10.8
         3 08:03:00
                          12.0
         4 08:04:00
                          11.5
In [71]: # Check for missing values
         missing_values = data.isnull().sum()
         print("\nMissing values:")
         print(missing_values)
         Missing values:
         Timestamp
         Flowrate
                      0
         dtype: int64
In [72]:
        # Data Cleaning: Remove rows with missing values
         data.dropna(inplace=True)
In [73]: # Data analysis
         # Plotting the flow rate over time
         plt.figure(figsize=(10, 6))
```

plt.plot(data['Timestamp'], data['Flowrate'], color='blue', marker='o', linestyle='

plt.title('Flowrate Over Time')

plt.xlabel('Timestamp')
plt.ylabel('Flowrate')

```
plt.xticks(rotation=45)
plt.grid(True)
plt.tight_layout()
plt.show()
```



```
In [75]: # Basic statistics of flow rate
         print("\nFlowrate statistics:")
         print(data['Flowrate'].describe())
         Flowrate statistics:
         count
                  20.000000
         mean
                  10.820000
                   2.450048
         std
         min
                   0.800000
         25%
                  10.775000
         50%
                  11.250000
         75%
                  11.925000
```

Name: Flowrate, dtype: float64

12.500000

In []:

max